

MultiGrip Backsplash Instructions

- 1) Make sure the wall is clean, dry and not exposed to direct sunlight
- 2) Cut several short pieces off of the MultiGrip roll that are about 1/2" shorter than the height of the wall (approx. 18") that you will be tiling.
- 3) Peel back (3-4") of the plastic liner downward along the 24" width, exposing the adhesive.
- 4) Facing the exposed adhesive towards the wall and starting at the top of the wall, up underneath the cabinet, press the MultiGrip onto the wall securely and evenly
- 5) Proceed to peel off more of the plastic liner downward in small portions as you slowly press the MultiGrip into place attempting to prevent wrinkles. If wrinkles do occur, simply use a small hard tool to flatten them down.
- 6) After each piece has been pressed into place, apply pressure by rubbing a clean dry cloth over the entire surface making sure that the MultiGrip is securely bonded to the wall.
- 7) Because MultiGrip is so thin, you can slightly overlap each sheet as you go.
- 8) Once the MultiGrip has been installed, you can immediately start to install your tile or you can wait a few days, if you wish.